



Asia-Pacific
Economic Cooperation



Asia-Pacific
Legal Metrology
Forum

Water Meters



APEC/APLMF Training Courses in Legal Metrology

September 23 – 26, 2008
Hanoi, Vietnam



Measurement
Canada

An Agency of
Industry Canada

Mesures
Canada

Un organisme
d'Industrie Canada

Canada

History

Oases Gadames

- Water meter in operation for 3000 years
 - Flow rate and time
 - Fair division given to all

History



Water Wheel

History




Water Delivery

History

Frontinus


- Frontinus appointed Water Commissioner of Rome in 95 AD
 - Identified issues
 - Fraud
 - Theft
 - Losses
 - Metering accuracy

History




Adjutage

History




Pitot Tube

History




Woltman Meter

History




Venturi Tube

History




Worthington Piston Meter

History



Oscillating Piston Meter

History



Nutating Disc Meter



Water Meters

"An instrument intended to measure continuously, memorize and display the volume of water passing through the meter at metering conditions."

OIML R 49-1

"A device which is used to measure the volume of water usage."


AWWA Manual M6

Water Meters

Applications for Water Utilities:

- Small size meters – residential/domestic
- Intermediate size meters – small commercial
- Large Meters – ICI
 - Industrial
 - Commercial – large
 - Institutional

Water Meters



Number of Domestic Meters (,000)

NA = North America

LA = Latin America

EU = Europe

MO+AF = Middle East + Africa

AS = Asia

Source: ARAD Meters




Customer Billing Water Utility Meters

- Positive Displacement
 - Fluidic Oscillator
- Velocity
 - Multi-jet
 - Single-jet
 - Turbine
 - Electromagnetic
 - Ultrasonic
- Compound (Combination)
- Fire-service

Positive Displacement Meter

- **Most Common:**
 - Oscillating Piston
 - Nutating Disc
- **Other Types:**
 - Sliding Vane
 - Oval Gear
 - Tri-rotor
 - Bi-rotor





Positive Displacement Meter

Operation:

- When operated under positive pressure, water physically displaces the moving measuring element in direct relation to the amount of water that passes through the meter.

Applications:

- Residential
- Small commercial

Positive Displacement Meter

Meter Size (mm)	Minimum Flowrate M ³ /h	Normal Flowrate M ³ /h
13	0.06	0.2 – 3.4
15	0.06	0.2 – 4.5
20	0.11	0.5 – 6.8
25	0.17	0.7 – 11.4
40	0.34	1.1 – 22.7
50	0.45	1.8 – 36.3

Source: AWWA C 700

Ex: Australia 20 mm PD meter

Minimum flow rate: 0.02 m³/h


Normal flow rate: 0.032 to 4.0 m³/h

Maximum flow rate: 5.0 m³/h

Positive Displacement Meters

Basic Meter Components:

Measuring
Element



Register

Maincase

Bottom Cap




Oscillating Piston Meter

- Water flows into a measuring chamber where it operates a piston.
- The piston moves freely and oscillates around a central hub.
- The piston is guided by a rubber-coated division plate.
- A drive magnet, incorporated in the piston, rotates around the outside of a hermetically sealed register well and magnetically drives the “follower” magnet sealed within the well.
- The “follower” magnet drives a crank connected to the register gear train, which translate the number of piston oscillations into volume totalization.


Oscillating Piston Meter

For each revolution of the piston a fixed volume of water is displaced



-  INFLOWING WATER
-  NEUTRAL WATER
-  EXHAUST WATER

Oscillating Piston Meter



Oscillating Piston Meter



Oscillating Piston Meter



**Measuring chamber – piston removed
(bottom view)**

Oscillating Piston Meter




**oscillating piston
(bottom view)**



Nutating Disc Meter

- Water flows into a measuring chamber where it causes a disc to nutate.
- The disc nutates freely on a ball.
- The disc is guided by a thrust roller.
- A drive magnet transmits the motion of the disc to a follower magnet located within the permanently sealed register. The follower magnet is connected to the register gear train.
- The gear train reduces the disc nutations into volume totalization units displayed on the register dial face.

Nutating Disc Meter





Nutating Disc Meter

[Play Badger Video](#)


Velocity Meter

Operation:

- A velocity-type meter measures the velocity of flow through a meter of a known internal capacity. The speed of the flow can then be converted into volume of flow usage.

Applications	Meter Type
residential/domestic	multi-jet single-jet
small commercial	multi-jet single-jet turbine
large ICI	single-jet turbine

Velocity Meter




Velocity Meter vs. PD Meter

Velocity Meter

- Sensing velocity of water
- Better precision if equipped with calibration device
- Functions in water containing impurities

PD Meter

- Sensing volume of water
- High precision no calibration
- Sensitive to water impurity



Geographical Implementation

(Domestic Meters)

Velocity Meter

- Rest of Europe, Southern USA
- Latin America
- Japan and Far East

PD Meter

- USA and Canada
- UK, France, Portugal, Cyprus
- H.K. Australia, Singapore



Source; ARAD Meter



Multi-jet Meter

Operation:

- Multi-jet meters use multiple ports surrounding the internal measuring chamber, to create a jet of water against an impeller.
- The impeller rotation speed is in relation to the velocity of water flow.
- A magnet and gear train converts the number of rotations into a volume which is displayed on the indicating device (register dial face).

Multi-jet Meter


Size and Flow Rates:

Meter Size (mm)	Minimum Flowrate M ³ /h	Normal Flowrate M ³ /h
15	0.06	0.2 – 4.5
20	0.11	0.5 – 6.8
25	0.17	0.7 – 11.4
40	0.34	1.1 – 22.7
50	0.45	1.8 – 36.3

Source: AWWA C 708

Multi-jet Meter

- Water flows via tangential entries and push the impeller.
- All impeller wings are in touch with water simultaneously while water flows.
- Some models equipped with an adjusting port to allow for recalibration, compensate for inaccuracy in older meters



Multi-jet Meter

Dry transmission
Magnetic transmission
between impeller and
the register



Wet Transmission
Direct transmission
between impeller and
register

Multi-jet Meter



India



China



USA



Single-jet Meter

Operation:

- A tapered inlet creating a single jet of water that is projected into the measuring chamber where it strikes the blades of the impeller.
- The impeller rotation speed is in relation to the velocity of water flow.
- A magnet and gear train converts the number of rotations into a volume which is displayed on the indicating device (register dial face).

Single-jet Meter


Sizes and Flowrates:

Meter Size (mm)	Minimum Flowrate M ³ /h	Normal Flowrate M ³ /h
13	0.007	0.03 – 3.4
15	0.015	0.06 – 4.5
20	0.029	0.12 – 6.8
25	0.057	0.17 – 11.4
40	0.11	0.34 - 23
50	0.11	0.45 – 36
75	0.11	0.57 - 73
100	0.17	0.68 – 110
150	0.34	0.91 – 220

Source: AWWA 712 & Actaris

Single-jet Meter

- **Body has only single water entry and exit.**
- **While water flows only one wing of the impeller is being touched**






Single-jet Meter


..\..\My Videos\RealPlayer Downloads\Flostar Video2.flv

Multi-jet vs. Single-jet



Multi- jet

- **High resistance to flow**
- **Longer life expectancy**
- **Many parts**
- **More expensive**
- **Less sensitive to installation conditions**
- **Most utilized meter worldwide**



Single jet

- **Limited resistance to flow**
- **Shorter life expectancy**
- **Economic solution**
- **Sensitive to installation conditions**
- **Popular for sub-metering applications**



Turbine Meter

Operation:

- Water passes through the meter and drives a rotor or vane
- The number of rotations of the rotor or vane is in direct proportion to the quantity of water passing through the meter.
- Rotor revolutions are transferred to an indicating device by appropriate reduction gearing, magnetic drives or electronic sensors.
- Vertical or horizontal rotor design
- AKA: woltman meter, helical rotor meter

Turbine Meter

Sizes and Flowrates:

Meter Size (mm)	Normal Flowrate M ³ /h
40	0.9 – 27
50	0.9 – 436
75	1.8 – 99
100	3.4 – 170
150	6.8 – 360
200	11 – 640
250	17 – 950
300	27 – 1,200
400	45 – 1,770
500	68 – 2,730

Source: AWWA 701



Turbine Meter


Play Badger Video



Turbine Meter

<http://www.sensusomni.com/>

Turbine Meter



Turbine Meter






Compound (Combination) Meter


Operation:

- Compound meters have two measuring elements and a changeover device valve to regulate flow between them.
- At high flow rates, water is normally diverted primarily or completely to the turbine part of the meter.
- When flow rates drop to where the turbine meter cannot measure accurately, a changeover device valve closes to divert water to a smaller meter.
- The low flow meter is typically a multi-jet or PD meter.
- The volume of water is displayed on a single register or by adding the registration of the high and low meter registers.


Compound Meter



Compound Meter




**High Pressure
High Flow**




**Low Pressure
Low Flow**

Compound Meter Components




Compound Meter Diagram



Compound Meter Operation


Low Flow



At low flow, the main valve prevents water from flowing through the Turbine element. All water is diverted through the cover, into the PD meter chamber and out the throttle tube.

Compound Meter Operation


Crossover
Imminent



As the flow rate increases, the increased pressure differential causes the valve piston to move rearward, closing the throttle tube door, reducing the flow through the PD meter chamber.

Compound Meter Operation


Crossover



The actuation of the valve piston and the subsequent reduction of flow through the PD meter chamber "shunts" a large volume of water through the turbine measuring element forcing the main valve open. Both the turbine and the PD meters are operating.

Compound Meter Operation

Intermediate and High Flow



At intermediate and high flow rates, the main valve is fully open and the majority of the water flows through the turbine. Water continues to flow through the PD meter at a greatly reduced rate. This helps “flush” the the PD meter while simultaneously insuring that it does not “over-speed”



Compound Meter


Play Badger Video (optional)

Compound Meter




Fluidic Oscillator Meter

- Fluidic oscillators work on the vortex meter principle.
- When a fluid passes by the obstruction, oscillations occur.
- Increasing flow increases the frequency of oscillation.
- A sensor detects the oscillations and an electronic transmitter generates a flow measurement signal.
- Examples of these oscillations in nature:
 - The swirls produced downstream of a rock in a rapidly flowing river
 - waving of a flag in the wind
- Aka: solid state meters.




Fluidic Oscillator Meter

Water enters the fluidic oscillator through a nozzle that forms an accelerated jet. When the jet enters the flow chamber, it will initially be drawn to one of the two diffuser walls. The jet will travel along the wall and then exit the flow chamber. At this point, a small portion of the flow will be caught in the feedback channel and be returned to the base of the incoming jet. This causes the jet to flip to the other side of the chamber, where it will travel along the other diffuser wall, and a small amount of water will be returned via the other feedback channel to repeat the process.



This oscillation between the diffuser walls continues while flow is present and its frequency is related to the rate of flow through the chamber. The oscillation is monitored by electrodes placed next to each diffuser wall. An electrical current is induced in the jet by a pair of powerful magnets within the flow chamber. The electrodes sense the induced current, from which the rate of oscillation is calculated and thus, over time, a measure of total flow is derived.

Fluidic Oscillator Meter




Electromagnetic Measurement

Use Faraday's Law to determine the flow of liquid in a pipe.

Magnetic field is generated and channeled into the liquid flowing through the pipe.

Flow of a conductive liquid through the magnetic field will cause a voltage signal to be sensed by electrodes located on the flow tube walls.

When the fluid moves faster, more voltage is generated. Faraday's Law states that the voltage generated is proportional to the movement of the flowing liquid. The electronic transmitter processes the voltage signal to determine liquid flow .





Electromagnetic Meters

- **Play Badger Video**



Electromagnetic Meters

○ Advantages

- Measurement independent of process pressure and temperature
- Large nominal diameter range (DN 2 to 3000)
- No moving parts
- No pressure loss
- No strainer required
- High accuracy, repeatability and long-term stability
- Measure liquids with entrained solids

○ Disadvantage

- Relatively expensive for small and minimum size meters
- Power Supply
- Deposits on measuring tube or electrodes can cause errors

Ultrasonic Meters

Ultrasonic (transit time) flowmeters send and receive ultrasonic waves between transducers.


At no flow conditions, it takes the same time to travel upstream and downstream between the transducers.

Under flowing conditions, the upstream wave will travel slower and take more time than the (faster) downstream wave.


When the fluid moves faster, the difference between the upstream and downstream times increases linearly.

The electronic transmitter processes upstream and downstream times to determine the flow rate.

NO FLOW



FLOW



Water Meters



Questions or Comments